

## Touch Screen

By touching the screen with your finger, you can control the audio system and air conditioning system, and adjust the screen display, etc. For details, refer to the "Owner's Manual".

### Basic operation



- 1 "CLIMATE": Air conditioning operation screen
- 2 "AUDIO": Audio control screen
- 3 "SETUP": Setup screen
- 4 "DISP": Adjust picture quality
- 5 "MAP/VOICE": Vehicle's current position
- 6 "DEST": Destination screen
- 7 "INFO/PHONE": Information screen

## ■ Set up screen


Press "SETUP" to display the "Setup" screen.



- 1 "General": General settings screen
- 2 "Clock": Clock settings screen
- 3 "Voice": Voice settings screen
- 4 "Navi.": Navigation settings screen
- 5 "Other": Other settings screen
- 6 "Vehicle": Vehicle settings screen
- 7 "Audio": Audio settings screen
- 8 "Phone": Phone settings screen

## ■ Information screen


Press "INFO/PHONE" to display the "Information" screen.




- 1 "Phone": Phone screen
- 2 "Fuel Consumption": Fuel consumption screen
- 3 "Map Data": HDD data screen
- 4 "Calendar": Calendar screen
- 5 "XM NavWeather": XM NavWeather™ screen
- 6 "XM Stocks": XM Stocks screen
- 7 "XM Sports": XM Sports screen
- 8 "LEXUS Insider": LEXUS Insider screen

## Display




Push the  button on the side of the touch screen to show the “Display” screen.

- 1 Turns the rear seat entertainment system on and off
- 2 Displays the screen in “Day Mode” with the headlight switch on
- 3 Turns the screen off
- 4 Adjust contrast
- 5 Adjust brightness
- 6 Adjust color tone
- 7 Adjust color



## Screen scroll operation



When any point on the map is touched, that point moves to the center of the screen.

- 1 Indicates the street name, city name, etc. for the selected point
- 2 Displays various information for the selected point (if available)
- 3 Indicates the distance from the current position to the pointer
- 4 Switches the screens
- 5 Zooms in on the map
- 6 Zooms out on the map

## Setting a route

While route guidance is operating, you can change the route using the following method.



Touch **Route**.

The following settings can be accessed




- 1 Detour setting
- 2 Route preferences
- 3 Route overview
- 4 Pause and resume route guidance

Some functions are unavailable while the vehicle is in motion. Refer to the "Navigation System Owner's Manual".

# Navigation System

## Register home



1 Push the  button on the side of the touch screen. (→P.42)


2 Touch .




3 Touch .

4 Touch .

5 Touch .



6 Touch .

7 Input a city name and touch .

8 Touch the button of the desired city name from the displayed list.


For security reasons, use a point close to your home instead of your actual home address.

9 Input the street name and touch .

10 When the desired street name is found, touch the corresponding button.



11 Input a house number and touch .


12 Touch .

13 Touch .

## Destination input — Search by address


### ► Select by city name



1 Push the  button on the side of the touch screen. (→P.42)

2 Touch  .

3 Touch  .

4 Input a city name and touch  .

5 Touch the button of the desired city name from the displayed list.

6 Input the street name and touch  .


7 When the desired street name is found, touch the corresponding button.

8 Input a house number and touch  .

9 Touch  .


10 Touch  .


## ► Select by street address




1 Push the  button on the side of the touch screen. (→P.42)

2 Touch .




3 Touch .



4 Input a house number and touch .

5 Input the street name and touch .

6 When the desired street name is found, touch the corresponding button.


7 Input a city name and touch .


8 Touch the button of the desired city name from the displayed list.

9 Touch .

10 Touch .


## Destination input — Search points of interest by name



1 Push the  button on the side of the touch screen. (→P.42)

2 Touch .

3 Touch .

4 Input the name of the point of interest and touch .


5 Touch the button of the desired destination.


6 Touch .

7 Touch .




## Destination input — Search points of interest by category



1 Push the  button on the side of the touch screen. (→P.42)

2 Touch .

3 Touch .

4 Touch .

5 Touch the button of the desired destination and set the search point.



6 Touch the desired point of interest category.


7 Touch the button of the desired item.

8 Touch .

9 Touch .


## Destination input — Search points of interest by telephone number



1 Push the  button on the side of the touch screen. (→P.42)

2 Touch .

3 Touch .

4 Input a telephone number and touch .


5 Touch .

6 Touch .

## Hands-free System For Cellular Phone

### Bluetooth® phone pairing

Compatible Bluetooth®-equipped phones can be connected to the vehicle, enabling hands-free operation. Please refer to the cellular phone manufacturer's user guide for pairing procedures, or go to "www.lexus.com/bluetooth" for more phone information.




To use a Bluetooth® phone, it is necessary to first register it in the system.

1 Push the  button on the side of the touch screen. (→P.42)

2 Touch .

3 Touch .

4 Touch  to display the screen for connecting Bluetooth®.





5 Enter the passcode displayed on the screen into the phone.  
Refer to the cellular phone user's manual for cellular phone operation.

6 When the connection is completed, **Bluetooth connection successful.** will appear



and push the  button.

## Phonebook transfer



1 Push the  button on the side of the touch screen. (→P.42)

2 Touch .

3 Touch .


4 Touch .

5 Touch .

6 Transfer the phonebook data to the system using the cellular phone.  
Refer to the cellular phone user's manual for cellular phone operation.


Phonebook transfer may not be possible depending on phone model.

## ■ Registering a voice tag



1 Push the  button on the side of the touch screen. (→P.42)

2 Touch .




3 Touch .



4 Touch .


5 Touch .

6 Touch the data you want to register.

7 Touch , and record a voice tag.

8 Touch .

## ■ Registering a speed dial



1 Push the  button on the side of the touch screen. (→P.42)

2 Touch .

3 Touch .

4 Touch .

5 Touch .

6 Touch the data you want to register.

7 Touch the desired phone number.

8 Touch the button you want to register in.

9 The registration completion message is displayed on the screen.

## ■ Calling by name


You can call by saying a voice tag registered in the phonebook. For setting the voice recognition, refer to the "Navigation System Owner's Manual". Only when English is selected as the system language can you call by saying a name registered in the phonebook without registering any voice tags beforehand. (Names in the phonebook work as voice tags.)



1 Pull .



- 2 Follow the voice guidance and say "Phone".
- 3 Follow the voice guidance and say "Dial by name".




- 4 Follow the voice guidance and say a contact name.
- 5 Follow the voice guidance and say the type of phone number (home, mobile, work, other).
- 6 Follow the voice guidance and say "Dial".




: Pulling this switch turns the voice command system on. Say a command after the beep.

## ■ Calling by speed dial



1 Press .





2 Touch .




3 Touch the desired number to call.



## ■ Receiving a call



- 1 When a call is received, this screen is displayed with a sound.

- 2 Push  on the steering wheel to talk on the phone.

To ignore the call, push  on the steering wheel.

## Audio System

The button positions, shapes and screen may slightly vary depending on the type of the audio system.

### Basic operation



1 Displays the audio control screen

2 Sound quality modes

3 Audio sources

#### ► Type A

**AM•FM:** AM radio/FM radio

**SAT:** Satellite radio

**DISC:** DVD player

**AUX•USB:** Auxiliary audio device/USB memory/iPod/Bluetooth® audio player

#### ► Type B

**AM:** AM radio

**FM:** FM radio

**DISC:** DVD player

**AUX•USB:** Auxiliary audio device/USB memory/iPod/Bluetooth® audio player

4 Power/Volume

### Radio



1 Displays the audio control screen

2 Station presets

3 Scanning radio stations

4 Radio tuner

5 Station select

6 Seek

## ■ Entering station presets

- 1 Touch the desired station by using the tune, seek or scan function.
- 2 Press and hold one of the preset buttons (1-6) until you hear a beep, indicating that the station is set.

## ■ DVD player/CD player

### ■ Playing an audio CD




- 1 Displays the audio control screen
- 2 Disc select
- 3 Repeat play
- 4 Random playback
- 5 Search playback
- 6 Disc load
- 7 Track select/rewind/fast-forward
- 8 Eject

### ■ Playing a CD with MP3/WMA files



- 1 Displays the audio control screen
- 2 Disc select
- 3 Repeat play
- 4 Random playback
- 5 Search playback
- 6 Folder select
- 7 File select
- 8 Disc load
- 9 Eject

## ■ Playing a DVD (DVD player only)



- 1 Displays the audio control screen
- 2 Disc select
- 3 DVD operation
- 4 Image display (full screen)
- 5 Disc load
- 6 Chapter select/rewind/fast-forward
- 7 Eject

## ■ Loading a disc

- 1 Press the "LOAD" button.
- 2 When the indicator changes from flashing amber to green, insert a disc after the disc slot door opens.

## ■ Loading multiple discs

- 1 Press and hold the "LOAD" button until you hear a beep.
- 2 When the indicator changes from flashing amber to green, insert a disc after the disc slot door opens.
- 3 After inserting a disc, wait until the indicator changes from flashing amber to green, then insert the next disc after the disc slot door has opened.

Repeat 2 and 3 until you have inserted all discs.

To cancel the operation, press the "LOAD" button. If you do not insert a disc within 15 seconds, loading will be canceled automatically.

## ■ Operating an iPod



- 1 Displays the audio control screen
- 2 Menu
- 3 Pause/Playback
- 4 Repeat play
- 5 Random playback
- 6 Song list
- 7 Song select
- 8 Song select/rewind/fast-forward

## ■ Remote control (steering wheel switches)

The audio system can be operated using the remote control located on the steering wheel.



- 1 Radio mode: radio tuner  
DVD mode: track/chapter/disc select  
CD mode: disc/track/file (MP3/WMA) select  
iPod mode: song select
- 2 Power on/change mode: press  
Power off: press and hold
- 3 Volume


## Front Air Conditioning System

### ► Without rear air conditioning system



CLYFQ50267E

### ► With rear air conditioning system



CLYFQ50268E

- |  |  |
|--|--|
| 1 "CLIMATE" (air conditioning operation screen display button) | 10 Driver side temperature display                         |
| 2 Air flow display   | 11 Automatic mode button                                   |
| 3 Fan speed display  | 12 Dual mode button  |
| 4 Passenger side temperature control                           | 13 Driver side temperature control                         |
| 5 Outside air/recirculated air mode button                     | 14 "A/C" button  |
| 6 Passenger side temperature display                           | 15 Rear air conditioning operation screen display switch   |
| 7 Micro dust and pollen filter button                          | 16 Air purifier and rear air conditioning operation switch |
| 8 Windshield defog/defrost                                     | 17 Individual mode button                                  |
| 9 "OFF" button   |  |

## ■ Using the automatic mode

---

- 1 Press the "AUTO" button.
- 2 Adjust the temperature using the "TEMP" buttons.

## ■ Adjusting the temperature in dual mode (without rear air conditioning system)

---

In dual mode, driver and passenger side temperature settings can be adjusted separately.

Press the "PASSENGER TEMP" button to adjust the temperature for the passenger side.  
To cancel the dual mode, press the "DUAL" button.

## ■ Adjusting the temperature in individual mode (with rear air conditioning system)

---

In individual mode, the temperature for the driver's, front passenger's and rear seats can be adjusted separately.

Press the "PASSENGER TEMP" button to adjust the temperature for the passenger side.  
To adjust the temperature for the rear seats, see P.65.  
To cancel the individual mode, press the "4-ZONE" button.

## ■ To turn off the airflow

---

Press "OFF".


## Rear Air Conditioning System (If Equipped)

### ► 5-seat models



CLYFQ5D175


### ► 4-seat models



CLYFQ5D176

- |   |   |
|---|---|
| 1 Changes the left side air outlet used | 7 Air volume display                      |
| 2 Left side temperature control         | 8 Right side air flow display             |
| 3 Automatic mode button                 | 9 Right side temperature display          |
| 4 "OFF" button                          | 10 Air volume controls                    |
| 5 Left side temperature display         | 11 Right side temperature control         |
| 6 Left side air flow display            | 12 Changes the right side air outlet used |

## Front controller (touch screen)



CLYFQ5D286E

- |   |
|---|
| 1 Left side temperature control switch and display  |
| 2 Off   |
| 3 Right side temperature control switch and display |
| 4 Fan speed display                                 |
| 5 Automatic mode button                             |



## Voice Command System

### Basic operation


**NOTE:** When inputting voice commands you must wait until after the beep to speak.



1 Pull .



2 - If you know the command:

Pull  again.

- If you do not know the command:  
Follow the voice guidance to learn the command and then pull  again.

3 Say a command after the beep.

#### ■ Important voice commands information and tips

- Voice commands can be used while driving.
- You must wait until after the beep to say a command.
- In vehicles with a navigation system, a large TALK icon  will appear on the navigation screen to prompt you to say a command.
- If you know what command to use, you can pull  at any time to interrupt the voice guidance.


## Heated Steering Wheel



To heat the leather portion of the steering wheel, press the button.


Press again to cancel.

## Rear Sunshade/Rear Door Sunshades




- 1 Rear sunshade
- 2 Rear door sunshades (if equipped)

## Raising/Extending from the front seat



### ► Without rear console display


- 1 Raises the rear sunshade  
Press the button again to lower it.
- 2 Extends the rear door sunshades  
Press the button again to retract them.



### ► With rear console display

- 1 Raises the rear sunshade  
Press the button again to lower it.
- 2 Extends the rear door sunshades  
Press the button again to retract them.

## ■ Raising/Extending from the rear seat




### ► 5-seat models

Slide the armrest lid.

- 1 Raises the rear sunshade
- 2 Extends the rear door sunshade (left side)
- 3 Extends the rear door sunshade (right side)

Press the button again to lower or retract the sunshade(s).



### ► 4-seat models

- 1 Raises the rear sunshade
- 2 Extends the rear door sunshade (left side)
- 3 Extends the rear door sunshade (right side)

Press the button again to lower or retract the sunshade(s).

The rear sunshade automatically lowers to ensure visibility when reversing.

## **Lexus Enform with Safety Connect (If Equipped)**

Lexus Enform and Safety Connect are subscription-based telematics services that use Global Positioning System (GPS) data, embedded cellular technology and XM<sup>®</sup> satellite data services to provide safety and security as well as convenience features to subscribers.

Lexus Enform and Safety Connect services are supported by Lexus' designated response center, which operates 24 hours per day, 7 days per week.

Lexus Enform service is available by subscription on select, telematics hardware-equipped vehicles.

For details, refer to the "Owner's Manual" and "Navigation System Owner's Manual".

### **Safety Connect system components**



- 1** Microphone
- 2** LED light indicators
- 3** "SOS" button

## ■ Services

---

► **With an active Lexus Enform subscription, the following features are available:**

● **Safety Connect**

- Automatic collision notification<sup>\*1</sup>

In case of either airbag deployment or severe rear-end collision, the system is designed to automatically call the response center. The responding agent receives the vehicle's location and attempts to speak with the vehicle occupants to assess the level of emergency. If the occupants are unable to communicate, the agent automatically treats the call as an emergency, contacts the nearest emergency services provider to describe the situation, and requests that assistance be sent to the location.

- Stolen vehicle location

If your vehicle is stolen, Safety Connect can work with local authorities to assist them in locating and recovering the vehicle. After filing a police report, call the Safety Connect response center at 1-800-25-LEXUS (1-800-255-3987) and follow the prompts for Safety Connect to initiate this service.

In addition to assisting law enforcement with recovery of a stolen vehicle, Safety-Connect-equipped vehicle location data may, under certain circumstances, be shared with third parties to locate your vehicle. Further information is available at [Lexus.com](http://Lexus.com).

- Emergency assistance button (SOS)

In the event of an emergency on the road, push the "SOS" button to reach the Safety Connect response center. The answering agent will determine your vehicle's location, assess the emergency, and dispatch the necessary assistance required.

If you accidentally press the "SOS" button, tell the response-center agent that you are not experiencing an emergency.

- Enhanced roadside assistance

Subscribers can press the "SOS" button to reach a Safety Connect response-center agent, who can help with a wide range of needs, such as: towing, flat tire, fuel delivery, etc. For a description of the Enhanced Roadside Assistance services and their limitations, please see the Safety Connect Terms and Conditions, which are available at [Lexus.com](http://Lexus.com).

- **Destination Assist**

Destination Assist provides you with live assistance for finding destinations via the Lexus Enform response center. You can request either a specific business, address, or ask for help locating your desired destination by category, such as restaurants, gas stations, shopping centers or other points of interest (POI).

After you tell the agent your choice of destination, its coordinates are sent wirelessly to your vehicle's navigation system.

- **eDestination**

With the eDestination feature, you can go online, via the Lexus.com owner's Web site, to select and organize destinations of your choice and then wirelessly send them to your vehicle's navigation system.

You can store up to 200 locations online to access and update at any time.

Your locations can be organized into up to 20 personalized folders.

You must first go online at [www.lexus.com](http://www.lexus.com) and go to the "Owners" section where you will need to register and log in. After this, you can create your personalized folders containing the locations you wish to send to your vehicle. (See Lexus Enform Guide for more information.)

- **XM<sup>®</sup> Sports and Stocks<sup>\*2</sup>**

XM<sup>®</sup> Sports and Stocks is a service included with XM<sup>®</sup> satellite radio subscriptions for Lexus Enform vehicles. With this service, you can receive updates via the navigation system on your personally selected sports teams and stocks.

- **XM NavWeather<sup>TM\*3</sup>**

The subscription-based XM NavWeather<sup>TM</sup> service allows the navigation system to display weather information on the map.

- **XM<sup>®</sup> NavTraffic<sup>\*3</sup>**

The subscription-based XM<sup>®</sup> NavTraffic service allows the navigation system to display traffic information on the map.

► The following navigation-based Lexus Enform features are available without a subscription:

● **Lexus Insider**

Lexus Insider is an optional service that can send audio messages, or articles, to participating owner's vehicles via the navigation system. Potential Lexus Insider subjects might include, for example, Lexus vehicle technology tips, updates on regional Lexus events, or audio excerpts from Lexus Magazine articles. Up to 20 articles can be stored at a time.

● **Voice Command**

The voice command system enables you to operate the navigation system, audio system and hands-free system by giving a command.

\*1: U.S. Patent No. 7,508,298 B2

\*2: Available at no extra charge with an active XM<sup>®</sup> satellite radio subscription.

\*3: Available via separate XM<sup>®</sup> subscription(s).

## ■ **Subscription**

---

After you have signed the Telematics Subscription Service Agreement and are enrolled, you can begin receiving services. A variety of subscription terms is available for purchase. Contact your Lexus dealer, call 1-800-25-LEXUS (1-800-255-3987), or touch "Destination Assist" or push the "SOS" button in your vehicle for further subscription details. XM NavTraffic<sup>®</sup> and XM NavWeather<sup>™</sup> require separate XM<sup>®</sup> subscription(s). XM<sup>®</sup> Sports and Stocks is available with an XM<sup>®</sup> Satellite Radio subscription. After a 90-day free trial, you must set up the appropriate XM<sup>®</sup> subscription(s) to continue receiving these services.